

TJ MICROWAVE RADIO SYSTEM TESTS NOISE LOADING MEASUREMENTS

This section outlines a procedure for noise load testing of a TJ transmitter-receiver link. The test is performed by supplying noise of a bandwidth, which simulates the busy-hour multiplex load, to the radio. The resultant noise is measured in a test slot at the receiver. A narrow slot in the noise is then cleared at the transmitter and the noise again measured in the slot under test at the receiver. The noise performance is obtained directly from this signal-to-no-signal comparison for various radio input levels.

This section is reissued to correct, revise, and rearrange the steps and drawings involved in the noise load testing of the TJ radio system. This reissue does not affect the Equipment Test List.

These tests are a critical analysis of the condition of not only the radio but also the waveguide/antenna system. Comparison of the noise-to-drive (V) curves obtained with the typical examples included in this section can pinpoint many problems. Recourse to noise figure and impedance-matching tests may correct high thermal noise, while linearity adjustments may reduce high intermodulation noise.

The V curves portray the signal-to-noise performance of the system with relation to deviation. The descending (left) part of the curve shows the signal "climbing out" of thermal noise and the ascending (right) portion shows the effects of intermodulation due to overdeviation. When these slopes are smooth and bottom near reference drive, conditions are normal (Fig. 4). Optimum performance at less than reference drive may be indicative of poor linearity, while optimum performance at more than reference drive indicates thermal problems. Irregularities in the curves (Fig. 5) may be due to delay and echo distortion and should be referred by way of the line organization.

Many types and models of noise loading test equipment are available, each with its own measurement procedure. However, adherence to the method outlined in this section should prove satisfactory with any of the specified equipment. The test frequency slots may differ with various test sets, but this is immaterial as long as the low-medium-high relationship is preserved.

APPARATUS:

- 1—Noise Generator with flat output versus frequency over the 600-channel LMX spectrum (Marconi 2091 or Siemens & Halske Rel 3W432A)
- 1—Selective Frequency Receiver (Marconi 2092 or Siemens & Halske Rel 3D335 with slot filters)
- 1—Band Rejection Filter Set (part of Marconi or Siemens & Halske transmitting equipment)
- 1—26A Split Pad, 6 dB

APPARATUS (Cont):

- 1—J64070B (70B) Power Meter
- 1—Type 19 Pad, 4 dB
- 2—KS-13388, L1 75-Ohm Attenuators or J99262AA TL Test Sets
- Test Cords (Supplied with IF Test Set and Noise Loading Set)
- 1—201B Repeat Coil or J68376C Impedance Matching Test Set

STEP

PROCEDURE

◆ **Caution:** Do not perform this test when fading is occurring as indicated by variations in the plate current of the main IF amplifier, (see Section 409-240-502 for more information, if necessary)◆

- 1 Remove the section from service in accordance with Section 409-240-500.
- 2 Make the test connections in accordance with Fig. 1, option (A).

Note: If necessary, install a band-defining filter at the noise generator output to limit the noise to the 600-channel LMX spectrum (this filter may be part of the noise generator).




Fig. 1—◆TJ Noise Loading—Test Connections◆

STEP	PROCEDURE
3	Select and install the low-frequency bandpass filter at the receiver (usually 70 kHz).
4	Set the receiver detector sensitivity to obtain a convenient midscale meter reference. Note this value.
5	<p>Insert the band-elimination filter, corresponding to that selected in Step 3, at the transmitter [Fig. 1, option (B)].</p> <p>Note: The power meter indication will decrease when the filter is inserted. It is not necessary to adjust the noise level unless the change is greater than 0.5 dB.</p>
6	Adjust the receiving attenuator to obtain the same meter reference indication as in Step 4.
7	<p>Record the setting of the receiving attenuator on a chart similar to that shown in Fig. 2. This is the noise in dB_{rnc0}.</p> <p>Note: In addition to recording the information, it is desirable to plot the data as it is taken in Fig. 3. Any error or trouble that may be encountered would immediately be evident.</p>

TJ RADIO 600-CHANNEL NOISE LOADING TESTS

DATE _____

SHEET _____

SYSTEM _____

SECTION _____

CHANNEL NUMBER _____

RECEIVED SIGNAL _____

FREQ UNDER TEST		70 KHZ (LOW)	290 KHZ	540 KHZ	1002 KHZ (MED)	2438 KHZ (HIGH)
TRMTR ATTEN SETTING	DB FROM REFERENCE					
46	-16					
42	-12					
38	-8					
34	-4					
32	-2					
30	-0					
28	+2					
26	+4					
22	+8					
18	+12					

Fig. 2—TJ Radio Noise Loading Data Sheet

TJ RADIO 600-CHANNEL NOISE LOADING

DATE _____
SHEET _____

SYSTEM _____
SECTION UNDER TEST _____

CHANNEL NUMBER _____
RECEIVED SIGNAL _____




Fig. 3—Recommended Form for Plotting Noise Loading Curves

STEP	PROCEDURE
8	Decrease the attenuation in the transmitter attenuator by 4 dB and reset the receiving attenuator to 65 dB.
9	Repeat Steps 4 through 7.
10	Repeat Steps 3 through 7 for each of the transmitting drive levels shown in Fig. 2 for the frequency under test. <i>Note:</i> If additional sensitivity is required at the noise receiver, the receiving attenuator setting may be decreased to 61 and 10 dB added to the results obtained.
11	Select the other frequencies to be tested (at least low, medium, and high) and repeat Steps 3 through 10.
12	From the recorded data obtained, read the high-slot noise at reference drive (2438 kHz at -30 dB into the TRS TST jacks). <i>Note:</i> The noise at reference drive should not be greater than the level shown in Table A for the measured received signal. Also the shape of the noise curves should be similar to those shown in Fig. 4. A typical unsatisfactory noise plot is shown in Fig. 5. If these objectives are not met and the system linearity and deviation are correct, refer the matter for further assistance by way of the line organization.

TABLE A

TJ RADIO — 1600 CARRIER MAXIMUM
ALLOWABLE NOISE PER HOP AT REFERENCE
DRIVE (WITHOUT PREEMPHASIS)

RECEIVED SIGNAL (DBM)	WORST CIRCUIT NOISE (TOP CHANNEL) AT REFERENCE
	DBRNC0
-30 to -33	25.0
-33 to -36	26.5
-36 to -38	27.5
-38 to -40	29.0

T J RADIO 600-CHANNEL NOISE LOADING

SYSTEM _____
SECTION UNDER TEST _____

CHANNEL NUMBER 6A
RECEIVED SIGNAL -40 DBM

DATE _____
SHEET _____




Fig. 4—Typical Satisfactory Noise Loading Plot

TJ RADIO 600-CHANNEL NOISE LOADING

DATE _____
SHEET _____

SYSTEM _____
SECTION UNDER TEST _____

CHANNEL NUMBER 1B
RECEIVED SIGNAL -36 DBM




Fig. 5—Noise Loading Plot—Unsatisfactory