PUB 42106

PRELIMINARY

Bell System Voice Communications
TECHNICAL REFERENCE

Voice Connecting Arrangement

CEBAV

Interface Specification

August 1970

ENGINEERING DIRECTOR - CUSTOMER TELEPHONE SYSTEMS

PRELIMINARY

NOTICE

This Technical Reference is specifically intended for the developers and designers of telephone voice communications systems and equipment which interface with the Bell System telecommunications network and for technical consultants to use in designing communications systems and arrangements requiring connections to the Bell System telecommunications network. The right to revise this Technical Reference for any reason, including conformity with USASI, EIA, CCITT or other standards, to utilize new advances in the state of the technical arts, or to reflect changes in the design of the equipment and/or service described herein, is expressly reserved.

If further information is required, please contact:

Engineering Director - Customer Telephone Systems
American Telephone and Telegraph Company
195 Broadway
New York, New York 10007

PREFACE

The material in this Technical Reference is intended for use by designers and manufacturers of telephone equipment who expect to connect their communications equipment to the Bell System telecommunications network. This material covers guides which, if followed, should permit the transmission and reception of voice signals without interference to other Telephone Company services.

The responsibility of the Bell System with respect to the use of customer-provided equipment is as set forth in the appropriate Tariff regulations.

In furnishing this material, the Bell System Telephone Companies make no claims or representations and assume no responsibility, beyond that set forth in the Tariff regulations, for the suitability of the transmission path or the performance of the telecommunications system. The Bell System is in no way responsible for the design, performance, installation, operation or maintenance of the communications systems or equipment provided by others which are connected to the telecommunications network and does not endorse or approve any such system or equipment. The material in this Technical Reference is furnished in the interest of preventing interference to other Telephone Company services and users, and is not furnished with the intent to provide complete design specifications or parameters, or to assure the quality or performance of customer-provided telephone systems and equipment.

PRELIMINARY

TABLE OF CONTENTS

PRELIMINARY

LIST OF FIGURES

1. GENERAL

F.C.C. Tariff No. 263 and corresponding intrastate Tariffs filed by the Bell System provide for the direct connection of customer-provided voice transmitting and receiving terminal equipment and communications systems to the Bell System telecommunications network. Direct electrical connection is made through a voice connecting arrangement furnished, installed, and maintained by the Telephone Company. The Tariffs also provide for the indirect (acoustic or inductive) connection of such equipment or systems.

In addition, the Bell System retains responsibility for network control signaling. This includes the switchhook, dialing and control functions, as well as responsibility for the protective function of voice signal limiting and isolation of Central Office battery from the customer-provided equipment.

The connection service described in this Technical Reference is identified by the Telephone Company as Voice Connecting Arrangement CEBAV and should be ordered as such. Contact your local Telephone Company business office or Marketing representative for information regarding rates for, and the availability of, this voice connecting arrangement for both new and additional service.

2. SYSTEM DESIGN CONSIDERATIONS

2.1 Voice Connecting Arrangement CEBAV

Voice Connecting Arrangement CEBAV provides a means for the customer to manually connect and disconnect customer-provided equipment capable of answering an incoming call, to a line terminated on a Telephone

Company-provided Key Telephone Set. This arrangement handles incoming calls and is intended for voice signals only. A talking path is established over the transmission leads. The customer-provided equipment must provide a momentary closure over one pair of leads to connect the customer-provided equipment to the line and must maintain this contact closure until it is removed by the attendant to disconnect.

2.2 Service and Maintenance Considerations

2.21 Responsibility of the Customer

The Tariffs permitting direct electrical connection of customer-provided communications systems state that:

> Where long distance message telecommunications service is available under this Tariff for use in connection with customer-provided communications systems the operating characteristics of such systems shall be such as not to interfere with any of the services offered by the Telephone Company. Such use is subject to the further provisions that the customer-provided systems do not endanger the safety of Telephone Company employees or the public; damage, require change in or alteration of, the equipment or other facilities of the Telephone Company; interfere with the proper functioning of such equipment or facilities; impair the operation of the telecommunications system or otherwise injure the public in its use of the Telephone Company's services. Upon notice from the Telephone Company that the customer-provided system is causing or is likely to cause such hazard or interference the customer shall make such change as shall be necessary to remove or prevent such hazard or interference.

2.22 Responsibility of the Telephone Company

The Tariffs permitting direct electrical connection of customer-provided communications systems state that:

> The Telephone Company shall not be responsible for the installation, operation, or maintenance of any customer-provided communications systems. Long distance message telecommunications service is not represented as adapted to the use of customer-provided systems and where such systems are connected to Telephone Company facilities the responsibility of the Telephone Company shall be limited to the furnishing of facilities suitable for long distance message telecommunications service and to the maintenance and operation of such facilities in a manner proper for such telecommunications service; subject to this responsibility the Telephone Company shall not be responsible for (i) the through transmission of signals generated by the customer-provided systems or for the quality of, or defects in, such transmission, or (ii) the reception of signals by customer-provided systems.
>
> The Telephone Company shall not be responsible to the customer or otherwise if changes in minimum network protection criteria contained in the Tariffs and Paragraph 5 of this Technical Reference, or in any of the facilities, operations, or procedures of the Telephone Company render any customer-provided facilities obsolete or require modification or alteration of such equipment or otherwise affect its use or performance.

2.23 Trouble Reporting Procedure

When trouble is experienced with this service, the customer should perform the necessary testing to sectionalize the difficulty by opening the circuit at the Interface Connecting Block and testing only toward the customer-provided equipment. If the tests indicate that the trouble is in the Telephone Company-provided equipment, it should be promptly reported to the Telephone Company. Trouble reports should be called into the listed "Repair Service" number which can be found in the front of the telephone directory. The repair attendant should be given:

(a) Customer's name.

(b) Customer's address.

(c) Listed telephone number.

(d) Description of the trouble.

(e) Customer's contact for additional information.

2.3 Foreign and Surge Voltage Protection

Where telephone lines are exposed to lightning, power circuit contact, or induction, protective devices are installed at the Central Office and on the customer's premises that will provide a path to ground for foreign voltages that exceed about 600 volts peak. Since the customer's equipment is connected to the telephone line through the voice connecting arrangement, the customer's equipment is protected from longitudinal surges by transformer isolation. The maximum surge between the transmission leads (conductors) that the customer's equipment may encounter due to foreign potential is 30 volts. The surge potentials on the other conductors of the voice connecting arrangement will not exceed about 600 volts peak.

The customer is responsible for providing protection, internal to his equipment and facilities, against foreign and surge voltages from his equipment and facilities being applied to the voice connecting arrangement. The surge potential on the transmission leads shall be limited to 30 volts. The surge potential on the other conductors shall be limited to 600 volts peak between conductors or from one conductor to ground.

2.4 Hazardous Voltage Limitations

When it is necessary for the customer to apply an operational voltage to the transmission or control leads of the voice connecting arrangement, certain voltage limitations shall be observed. These limitations are for the purpose of providing adequate protection to personnel and plant facilities. Unless otherwise specified in Paragraphs 4.2 and 4.3 of this Technical Reference, steady-state voltages applied by customer-provided equipment to conductors connected to Voice Connecting Arrangement CEBAV should not exceed the following:

	dc	ac(RMS)
Maximum voltage, any conductor to ground	135	50
Maximum voltage, conductor to conductor	(135 (270*	(50 (100*

*Permitted only if voltage source is center-tapped to ground.

The power supplies and wiring methods used in the customer-provided equipment should meet the provisions of the National Electrical Code (NEC), Article 725, for Class 2 remote control and signal circuits.

3. DESCRIPTION OF VOICE CONNECTING ARRANGEMENT CEBAV

3.1 Physical

Voice Connecting Arrangement CEBAV consists of a standard Central Office exchange line appearance on a Bell System Key Telephone Set and a voice connecting unit (Fig. 1). The unit is a 4 by 5 inch plug-in, printed wiring board. The associated apparatus mountings for the unit will be installed by the Telephone Company in the same location as the equipment which provides the Bell System key telephone service. This unit will function satisfactorily within a temperature range of 0° to 55°C and a humidity range from 5 to 95 percent. Each unit dissipates approximately 3 watts of heat. Leads from the unit will be terminated on a Telephone Company-provided Interface Connecting Block (Fig. 2) conveniently located to permit testing, maintenance, trouble isolation, and ease of connection to the customer-provided equipment. The customer-provided equipment should be located so that the maximum external loop resistance across the CS and CG leads measured at the Interface Connecting Block shall not exceed 50 ohms when indicating a closure.

3.2 Functions

The major functions of this voice connecting arrangement are:

(a) To protect Telephone Company personnel and equipment from hazardous voltages which may be applied at the interface.

(b) To provide voice-only access to the telecommunications network.

(c) To provide network control signaling to the network.

(d) To limit abnormally high voice signal levels to the telecommunications network.

(e) To provide for accepting supervisory signals from customer-provided equipment.

3.3 Operation

3.31 Connecting to an Incoming Call or Outgoing Call

When the user at the Bell System Key Telephone Set (Control Station) is busy on a call and an incoming call is received on a line associated with Voice Connecting Arrangement CEBAV, the user may operate the customer-provided contact closure on the CONNECT leads (CS and CBL) in order to activate the voice connecting unit (Fig. 3). This causes the unit to trip ringing and connect the line to the customer-provided equipment over the TRANSMISSION leads (CT and CR) typically, in order to answer the call via a recorded announcement. The handset of the Control Station must remain off-hook to maintain the connection.

3.32 Disconnect

The customer-provided equipment may be disconnected from the line by opening the contact closure on CONNECT leads (CS and CBL). When this open occurs the voice connecting unit releases. The connection to the line may be maintained to a Key Telephone Set by depressing the pickup key associated with the line at any Key Telephone Set before the CONNECT closure is released. If the Control Station handset goes on-hook, the voice connecting unit is also released.

3.4 Interface Leads

Four interface leads per circuit are provided from Voice Connecting Arrangement CEBAV to the Interface Connecting Block (Fig. 2) for the customer's use. Technical information pertaining to these leads is discussed in Paragraph 4.

The TRANSMISSION leads designated CT and CR provide a 2-way transmission path from the voice connecting arrangement. CONNECT leads designated CS and CBL provide an operate and hold path for the connect relay in the voice connecting unit.

3.5 Method of Connection

Leads from Voice Connecting Arrangement CEBAV will be terminated by the Telephone Company on the Interface Connecting Block. The customer or his representative must provide and install the conductors (22 to 26 gauge wire) and make the necessary connection to associate customer-provided equipment with the voice connecting arrangement at this Interface Connecting Block using a Reliable Electric R714B Tool or equivalent for the "quick connect" block shown in Fig. 2. The leads will be designated as follows:

Lead Designation	Function
CT CR	voice transmission
CS CBL	connect

4. ELECTRICAL CHARACTERISTICS

4.1 General

The insertion loss of Voice Connecting Arrangement CEBAV is a nominal one (1) dB over the voice frequency range of 300 to 3000 Hz. No voice signal amplification is provided.

4.2 Transmission Path

4.21 Voice Signal Limiter

A voice signal limiter is incorporated in the transmission path to protect the Bell System telecommunications network from applications of abnormally high signal levels. This has no effect on normal voice signal levels.

This limiter does not remove the customer's responsibility to meet the network protection criteria as prescribed in the Tariffs and as outlined in Paragraph 5 of this Technical Reference.

4.22 Transmission Parameters

Voice Connecting Arrangement CEBAV provides a one-to-one impedance transformation. The input impedance is a function of the impedance of the voice connecting arrangement and the impedance of the loop to the Central Office. For design purposes, the input impedance of this voice connecting arrangement should be considered to be 600 ohms and, therefore, the impedance of the customer-provided equipment should also be 600 ohms. The voice signal levels must comply with the applicable Tariffs. The Tariffs permitting electrical connection of customer-provided communications systems state:

> "To prevent excessive noise and crosstalk in the network, it is necessary that the power of the signal at the Central Office not exceed 12 dB below one milliwatt when averaged over any 3-second interval. To insure that this limit is not exceeded, the power of the signal which may be applied by the customer-provided equipment to the Telephone Company interface located on the customer's premises will be specified for each type of connecting arrangement, but in no case shall it exceed one milliwatt."

For Voice Connecting Arrangement CEBAV the maximum permissible voice signal power at the Interface Connecting Block is -8 dBm when averaged over any 3-second interval.

4.3 Signaling Paths

When a connection is initiated, the customer's equipment is expected to provide a momentary closure between the CS and CBL leads to operate the

relay in the voice connecting unit. The transmission path will cut through to the customer's equipment after closure of the CS and CBL leads, and will remain connected until these leads are opened at the customer-provided equipment or the Control Station goes on-hook.

The customer-provided contact should be isolated from ground and contain no foreign potentials. Open circuit resistance should exceed 15,000 ohms and short circuit resistance, including the external loop resistance, should not exceed 50 ohms.

The CS lead has a maximum of -28 volts dc through 590 ohms and the CBL lead is grounded. The CS and CBL leads will carry a .07 ampere, maximum, inductive load to the customer-provided equipment.

4.4 Grounding

In general, it is desirable that circuits in the customer's equipment which connect to the transmission leads of the voice connecting arrangement have some path to ground. A direct or resistive ground on one side of the power supply would be an example of such a path. This practice avoids the possibility of the entire circuit involved being at an indeterminate potential with respect to ground. Such a potential, perhaps as a result of electrostatic induction, could result in an insulation breakdown in this arrangement. It is expected that the customer's equipment, if powered from commercial power, will be grounded in accordance with applicable electrical codes (NEC) and should be bonded to the same ground to which the telephone protector ground electrode is attached. Self-powered or passive customer's equipment need not be grounded.

Voice Connecting Arrangement CEBAV is provided with a common signal ground which must be bonded to a metallic cold water pipe or other NEC approved ground serving as the electric power ground and telephone protector

ground where present. The CBL lead is grounded from the switchhook contacts of the Control Station. It is not permitted to derive the main ground for the customer's equipment through this lead from the voice connecting arrangement.

As an example, a good ground may be obtained with a proper connection to a metallic cold water pipe, using a single No. 14 or larger AWG copper conductor. The other end should be connected to the ground return terminal of the customer's equipment. The run should be short, straight, and a continuous piece of wire. Proper attention should be given to providing the lowest possible resistance connection at each end of the circuit. It is imperative that this ground be connected at the same location to the ground serving as the telephone protector or signal ground but not using the telephone ground clamp. This lead shall not be fused.

5. POWER AND IMPEDANCE CONSIDERATIONS FOR CUSTOMER-PROVIDED EQUIPMENT

5.1 Average Power at the Central Office

The average power (in any 3-second interval) delivered to a 900 ohm resistive load at the local Central Office should not exceed -12 dBm. The limitations described in 5.2 below, on power at the customer's location, have been set to meet an average of -12 dBm when all loops in the Bell System are considered.

5.2 Maximum Available Power

The local Central Office power criteria, in 5.1 above, will be considered to be satisfied by limiting the maximum available power* from a customer-provided 600 ohm source to -8 dBm measured across 600 ohms resistance when averaged over any 3-second interval. The customer-provided

*The available power of a source is the maximum power that the source can deliver to a load. Maximum power transfer occurs when the load source impedances are matched.

communications system should be so designed that the average power over any 3-second interval applied to the Interface Connecting Block associated with Voice Connecting Arrangement CEBAV does not exceed -8 dBm. The recommended procedure for estimating the power is given in Paragraph 6.

5.3 Signaling Considerations

The telecommunications network incorporates tone signaling devices that are used for network control functions. These devices, connected at all times to the telephone circuit, are designed to be sensitive to single frequency tones at 2600 Hz. They are, however relatively insensitive to energy at this frequency if sufficient energy is present at the same time in other frequencies in the voiceband.

In order to prevent the interruption or disconnection of a call, or interference with network control signaling, it is necessary that the signal applied by the customer-provided equipment to the voice connecting arrangement at no time have energy solely in the 2450 to 2750 Hz band. If signal power is in the 2450 to 2750 Hz band, it must not exceed the power present at the same time in the 800 to 2450 Hz band.

5.4 Out-of-Band Limits

To protect other services it is necessary that the signal applied by the customer-provided equipment to the Telephone Company interface located on the customer's premises meet the following limits:

(a) The power in the band from 3995 Hz to 4005 Hz shall not exceed 26 dB below the power of one milliwatt.

(b) The power in the band from 4000 Hz to 10,000 Hz shall not exceed 16 dB below one milliwatt.

(c) The power in the band from 10,000 Hz to 25,000 Hz shall not exceed 24 dB below one milliwatt.

(d) The power in the band from 25,000 Hz to 40,000 Hz shall not exceed 36 dB below one milliwatt.

(e) The power in the band above 40,000 Hz shall not exceed 50 dB below one milliwatt.

5.5 Internal Impedance

The internal impedance of the customer's equipment should be approximately 600 ohms.

6. TESTING AND MEASURING METHODS

6.1 Measuring Maximum Available Power

The following measuring method is satisfactory for estimating the maximum power averaged over a 3-second interval to determine that the inband criterion is being met:

Operate the customer-provided equipment into a 600 ohm load, (this assumes that the customer-provided equipment has a 600 ohm source impedance) bridged by a Hewlett-Packard Transmission and Noise Measuring Set - Model 3555B or a Western Electric 3-Type Noise Measuring Set, or the equivalent.* While these meters are nearly equivalent, the arrangement of control switches differ. To insure a proper measurement technique, the control settings on these meters should be as shown below.

Western Electric 3-Type Noise Measuring Set		Hewlett-Packard Transmission and Noise Measuring Set Model 3555B	
Control	Setting	Control	Setting
FUNCTION (Switch)	BRDG	INPUT (Switch)	NOISE/BRDG
NORM/DAMP (Switch)	DAMP	FUNCTION (Pushbutton)	VF/Nm-600BAL
WTG (Plug-in Network)	3Kc FLAT	NOISE WTG (Switch)	3kHz FLAT
		NORM/DAMP (Switch)	DAMP

*These meters do not have a 3-second averaging time, but when used on speech they give a reliable estimate of a 3-second average.

In almost all cases the speech power, averaged over any 3-second interval, will not exceed -8 dBm if the maximum meter swing does not exceed 85 dBrn.

The accuracy of this method can be somewhat improved by increasing the size of the damping capacitance in the Western Electric 3-Type Noise Meter by 150 microfarads. To do this, connect the negative lead of a 150 microfarad capacitor to either terminal of the NORM/DAMP switch and connect the positive lead to ground. This allows the meter to more nearly approximate a 3-second averaging meter. (NOTE: This modification does not necessarily hold for noise meters other than the Western Electric 3-Type.) With the additional damping the power averaged over any 3-second interval will not exceed -8 dBm (3kHz FLAT) if the maximum meter swing does not exceed 83 dBrn. The use of meters with shorter time constants, such as a VU meter or a standard voltmeter, is not recommended.

7. TELECOMMUNICATIONS NETWORK CHARACTERISTICS

7.1 Transmission Parameters

Information describing the component parts and operating characteristics of the Bell System telecommunications network has been published. Various articles listed in Paragraph 8 have discussed statistical information on talker volumes (a), end-office losses and noise (b-d), loop characteristics (e), and other characteristics (f-h). In addition, five general information texts are listed.

The 1000 Hz insertion loss for this voice connecting arrangement with a customer's communication device having a 600 ohm source impedance and its associated loop to the Central Office will average about 4 dB with a standard deviation of about 1.0 dB.

7.2 End-to-End Electrical Loss

The end-to-end electrical loss of a connection is a function of the impedance of both end terminations, the losses of the loops at both ends, and the end-office loss. The information given in the REFERENCES may be used to determine statistical loss distributions for different types of calling patterns of the telephone network.

7.3 Bandwidth and Frequency Response

The nominal voice frequency bandwidth of the telecommunications network extends from about 300 to about 3000 Hz. In general, an end-to-end connection may be expected to have a loss characteristic which increased with increasing frequencies in the upper half of the band. This voice connecting arrangement does not limit this bandwidth.

7.4 Nonlinearities

Nonlinearities such as compression, clipping, and harmonic distortion can exist on the telecommunications network. Normally, these are low enough to be ignored. It is expected that total harmonic distortions no greater than about 5 percent of the fundamental will normally be encountered.

8. REFERENCES

Some references describing various transmission characteristics of the telecommunications network are listed below:

(a) McAdoo, K. L., "Speech Volumes on Bell System Message Circuits - 1960 Survey," Bell System Technical Journal (BSTJ), Vol. 42, No. 5 (September 1963), p. 1999.

(b) Nasell, I., "The 1962 Survey of Noise and Loss on Toll Connections," BSTJ, Vol. 43, No. 2 (March 1964), p. 697.

(c) Nasell, I., "Some Transmission Characteristics of Bell System Toll Connections," BSTJ, Vol. 47, No. 6 (July-August 1968), p. 1001.

(d) Nasell, I.; Ellison, C. R.; and Homstrom, R., "The Transmission Performance of Bell System Intertoll Trunks," BSTJ, Vol. 47, No. 8 (October 1968), p. 1561.

(e) Gresh, P.A., "Physical and Transmission Characteristics of Customer Loop Plant," BSTJ, Vol. 48, No. 10 (December 1969), p. 3337.

(f) Alexander, A. A.; Gryb, R. M.; and Nast, D. W., "Capabilities of the Telephone Network for Data Transmission," BSTJ, Vol. 39, No. 3 (May 1960), p. 431.

(g) Breen, C., and Dahlbom, C. A., "Signaling Systems for the Control of Telephone Switching," BSTJ, Vol. 39, No. 6 (November 1960), p. 1381.

(h) Bodle, D. W., and Gresh, P. A., "Lightning Surges in Paired Telephone Cable Facilities," BSTJ, Vol. 40, No. 2 (March 1961), p. 547.

*(i) "Principles of Electricity Applied to Telephone and Telegraph Work," by American Telephone and Telegraph Company, New York, New York.

*(j) "Switching Systems," by American Telephone and Telegraph Company, New York, New York.

(k) "Notes on Transmission Engineering," by United States Independent Telephone Association, Washington, D.C.

*(l) "Notes on Distance Dialing - 1968," by American Telephone and Telegraph Company, New York, New York.

*(m) "Transmission Systems for Communications," by Bell Telephone Laboratories.

*Available through Graybar Electric Company.

9. GLOSSARY*

COMMUNICATIONS SYSTEMS - denotes channels and other facilities which are capable, when not connected to Long Distance Message Telecommunications Service, of communications between customer-provided terminal equipment or Telephone Company stations.

CONTROL STATION - the Bell System Key Telephone Station Set, furnished, installed, and maintained by the Telephone Company, used to originate and receive calls in the telecommunications network and to control the associated voice connecting arrangement.

CUSTOMER-PROVIDED TERMINAL EQUIPMENT - denotes devices or apparatus and their associated wiring, provided by a customer, which do not constitute a communications system and which, when connected to the communications path of the telecommunications system, are so connected either electrically, acoustically or inductively.

END-OFFICE - the last serving Central Office in the switching hierarchy of the telecommunications network.

INTERFACE CONNECTING BLOCK - the Telephone Company furnished connecting point to which the customer brings and connects the leads of his equipment, and to which the Telephone Company brings and connects leads from the voice connecting arrangement.

NETWORK CONTROL SIGNALING - denotes the transmission of signals used in the telecommunications system which perform functions such as supervision (control, status, and charging signals), address signaling (e.g., dialing), calling and called number identification, audible tone signals (call progress signals indicating reorder or busy conditions, alerting, coin denominations, coin collect and coin return tones) to control the operation of switching machines in the telcommunications system.

*May differ in letter from exact wording as used in the Tariffs.

TELECOMMUNICATIONS NETWORK - the Bell System voice switching equipment, associated interconnecting facilities and station equipment which connected its customers together.

TELEPHONE COMPANY - denotes the American Telephone and Telegraph Company, Long Lines Department, its concurring carriers and its connecting carriers, either individually or collectively.

VOICE CONNECTING ARRANGEMENT - the connection service provided by the Telephone Company to accomplish the direct electrical connection of customer-provided equipment with the telecommunications network.

VOICE CONNECTING UNIT - that portion of Voice Connecting Arrangement CEBAV that provides the actual connection between the customer-provided equipment and the facilities and equipment of the Telephone Company.

TYPICAL BELL SYSTEM KEY TELEPHONE SET
(NETWORK CONTROL SIGNALING UNIT)
FIG. 1A



VOICE CONNECTING UNIT
FIG. 1B

VOICE CONNECTING ARRANGEMENT CEBAV
FIG. 1



TYPICAL INTERFACE CONNECTING BLOCK
FIG. 2



BLOCK DIAGRAM – VOICE CONNECTING ARRANGEMENT CEBAV
FIG. 3



SIMPLIFIED SCHEMATIC – VOICE CONNECTING ARRANGEMENT CEBAV
FIG. 4