

SERVICE

2754-TYPE TELEPHONE SETS

1. GENERAL

1.01 This section provides maintenance and connection information for the 2754-type telephone sets. Maintenance information was previously contained in Section 502-750-102. Connection information was previously contained in Section 502-750-434 which is hereby canceled.

2. MAINTENANCE

2.01 Maintenance performed on customer's premises should be limited to replacement of accessible parts which are available through supply channels.

2.02 Ringers, handsets, dials, etc. used in this type set should be maintained in accordance with sections covering the particular item.

Note: When ringer volume control is set in LOW position only ringer motor noise may be heard because clapper might not strike gong. If bell sound is desired, move control to slightly higher volume position.

2.03 The exterior of the set should be clean and not marred or chipped. The vinyl-faced mat may be cleaned with a water-dampened KS-2423 or equivalent cloth. Replace defective mat as follows:

- (1) Grasp mat retainer frame at top, lift upward and out to release frame from panel of set.
- (2) Remove handset from hook of set.
- (3) Pull out handset cord to allow working slack.
- (4) Remove mat from face of panel.

- (5) Remove grommet from mat as shown in Fig. 1.
- (6) Install grommet in new mat by reversing procedure used in removal.
- (7) Position mat on panel and secure using the mat retainer frame.




Fig. 1—Removal of Handset Grommet

2.04 To test the cord reel, pull the handset cord out to its maximum length. With the cord maintained perpendicular to the panel, the cord

should retract fully. Any twist in the cord should be removed before making test.

2.05 Replace the cord reel if the cord will not retract or if the cord is frayed, kinked, or noisy. Field maintenance of the cord reel, or replacement of the cord, is not recommended.

Note: When replacing the cord reel use either the 3A or 3B when the telephone set is not subjected to temperatures below 40 degrees F. Below 40 degrees F only the 3A cord reel should be used.

TABLE A
POLARITY GUARD CONNECTIONS
(P-90D061 GUARD ASSEMBLY)

WIRE OR LEAD		REMOVE FROM	CONNECT TO	
		NET.	POLARITY GUARD	NET.
Dial	BK	RR	T	
	G-W	C	S	
Line Switch	W	C	S	
Polarity Guard	G			RR
	W			C

Note: For use when specified by local instructions for end-to-end signaling installations.

TABLE B
CONNECTIONS FOR LINE EXCLUSION

EXCLUSION	KEY TELEPHONE SYSTEM	EXCLUSION KEY LEADS							
		(BL-W)	(W-BL)	(O-W)	(W-O)	(V-BL)	(BL-V)	(V-O)	(O-V)
On any Line	1A	R*	T*	1B‡	H*	ET	ER	EH	EB
	1A1 or 1A2	R*	T*	†	H*	ET	ER	EH	EB

* Terminal of line involved.

† Insulated and stored

‡ When other than Line 1 is excluded, remove O-W cord conductor from terminal 1B; insulate and store. Connect balance lead cord conductor of line involved to terminal 1B.

TABLE C
PICKUP-SIGNAL KEY CONVERSION (NOTE 1)

CONVERSION OPTIONS	635A2 KEY LEADS			STRAP
	(Y-BR)	(BR)	(BR-BK)	(S-R)
HPPPPP	M	M	X	M
HPPPPS	M	M	SG	M
HPPPSS	M	M	X	SG
HPPSSS	M	X	X	SG
HPPPP*S*	M	M	Note 3	5H
HPPP*P*S*	M	X	Note 3	5H
HPP*P*P*S*	X	X	Note 3	5H

*See Note 2.

Notes:

1. As furnished, all line keys are arranged for pickup. To convert a key position from pickup (locking) to signal (nonlocking), remove the P-28E773 locking pin from plunger at the key position to be converted. To convert a key position from nonlocking to locking, insert P-28E773 locking pin.
2. These options are used for private or intercommunicating lines with a common signal key. Use line switch controlled ground lead for common signal ground and S lead of 2nd, 3rd, or 4th pickup key as required. The signal key will operate the signal circuit of the selected line. Connect as shown in Table C for the appropriate KTS.
3. For 1A1 and 1A2 KTS, move key lead (BR-BK) from terminal X to terminal N. For 1A KTS, move key lead (BR-BK) and strap (BK) from terminal N and connect together at any spare terminal.

SECTION 502-738-402





Fig. 2—2754-Type Telephone Set, Connections (Sheet 1 of 2)



NOTES:

1. IF CAPACITOR IS NOT REQUIRED MOVE (R) RINGER LEAD TO A.
2. 75A CONNECTING BLOCK SHOWN. CONNECTOR CABLE MAY BE CONNECTED DIRECTLY TO PLUG. COLORS AND PIN NUMBERS FOR CONNECTOR CABLE ARE SAME AS MTG CORD.
3. FOR EXCLUSION FEATURE CONNECT SWITCH LEADS PER TABLE B.

*- INSULATED AND STORED.
 † NETWORK TERMINALS - UNDESIGNATED TERMINALS ARE ON KEY TERMINAL BOARD.

H- HOLD KEY
 LS- LINE SWITCH
 PU- PICKUP KEY
 ⊙- TERMINAL WITH SCREW
 ○- TERMINAL WITHOUT SCREW
 []- 3A CORD REEL LEAD COLORS.
 ()- 3B CORD REEL LEAD COLORS.

TABLE D
KEY PLUG COLOR CODE

COLOR	BLUE	ORANGE	GREEN	BROWN	SLATE	PINK
CODE	A	B	C	D	E	F

Fig. 2—2754-Type Telephone Set, Connections (Sheet 2 of 2)

