

155C, D, G, H

COMMON BATTERY — CONNECTIONS




Fig. 1 — Circuit Diagram for Use with 634A, BA, BC; 684A, BA, BC Induction Coil Type Subscriber Sets




Fig. 2 — Circuit Diagram for Use with 634CG, CH (Long Loops) and 634CK, CL; 684CK, CL (Inductive Noise Reduction) Induction Coil Type Subscriber Sets

See notes Page 2

Note 1: In some upper housings, terminals may be designated Y, BB, YY, W, and BK-YY, respectively. Terminal 5 is not always furnished.

Note 2: Dotted lines in diagram show manual set connections.

Note 3: When a 61R filter is required for radio frequency suppression, move yellow dial lead from Y upper-housing contact spring to filter bracket terminal, and connect filter leads as follows:

- Yellow lead to filter bracket terminal.
- Black lead to A terminal on chute.
- Red lead to Y upper-housing contact.