




ASUS VivoBook S400C Hard Drive Replacement

How to replace the hard drive for the ASUS VivoBook S400C.

Written By: Tiana Curry



INTRODUCTION

If your ASUS VivoBook S400C hard drive is making clicking and humming sounds, or if your programs are repeatedly crashing, use this guide to replace your hard drive. Before beginning, make sure to power off your laptop completely and disconnect from any external power source.

Note: As this is a 2.5" hard drive, if you are looking to replace this hard drive be sure to get one that is 2.5"s.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [ESD-safe pry tool](#) (1)

Step 1 — Battery




- Flip the device over and remove the ten 5.7 mm screws with a Phillips #0 screwdriver.

Step 2




- Use a spudger or your fingers to go around and lift the edges and release the back panel.

Step 3




- Using a spudger, lift up the ribbon cable connecting the battery to the motherboard.

Step 4




- With a Phillips #0 screwdriver, remove the four 5.7 mm screws holding the battery to the laptop.

Step 5




- Carefully lift the battery up and out of the device.

Step 6 — Hard Drive



- Remove the three Phillips #0 screws holding the the hard drive in place: two 3.8 mm screws, and one 5.7 mm screws

Step 7



- Pull left and lift out the hard drive.

To reassemble your device, follow these instructions in reverse order.