



Acer Aspire S7-392-6484 Solid State Drive Replacement

Replace your Solid State drive to return speed and efficiency to your Acer Aspire.

Written By: Nicholas Wise




INTRODUCTION

How to replace the solid state drive in an Acer Aspire S7-392-6484.

TOOLS:



- [Phillips #1 Screwdriver \(1\)](#)
- [T6 Torx Screwdriver \(1\)](#)

Step 1 — Fan




- Remove the back panel by unscrewing all marked 3mm screws with a T6 Torx screwdriver.
- Remove these screws with a T6 Torx screwdriver, but note that these feet screws are 4mm in length.

Step 2




- Unscrew the marked 2mm screws with a Phillips #01 screwdriver.
- Remove the fan by disconnecting the marked tabs.

Step 3 — Solid State Drive



- Remove the marked 2mm screw with a Phillips #01 screwdriver.

Step 4



 Remove the hard drive by pulling it away horizontally from its connection.

To reassemble your device, follow these instructions in reverse order.