



Amazon Fire HD 10 Battery Replacement

Follow this guide to replace your battery.

Written By: Jaie Hillary



INTRODUCTION

Before you begin, make sure the device is off. You will need to use the screen replacement guide as a prerequisite.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Spudger](#) (1)

Step 1 — Screen



! Avoid prying near bottom right hand side due to LCD Connector

- Use a plastic opening tool to pry the screen up in the right hand corner.


Step 2



! Do not completely remove the screen yet as there is a ZIF connector connected.

- Lift the screen and digitizer from the case.
- i You may need to use some force due to the glue.

Step 3



(i) Be mindful of the ZIF connector.


- Disconnect the ribbon connector from the digitizer side using your hands or the plastic opening tool.

Step 4



- Remove the screen and digitizer from the case completely.

Step 5 — Battery



- Locate the power cable that links the battery to the motherboard.
- Carefully unplug the battery power cable to disconnect the battery from the motherboard.
- *(i)* The third image shows what it should look like with the battery power cable is disconnected.

Step 6



- Begin by locating the double sided pull tape locations.
- ⚠** Do not lift on the battery when doing the following step. You will bend it. It is very pliable.
- Pull the black soft tabs to release the tape's adhesion.
- *(i)* Make sure you pull the tabs slowly and continuously away from the case until the adhesive is completely out.
- Do this to all 4 tabs until the battery is completely free of adhesion to the device's backing.

Step 7



! Make sure all the adhesive is removed before trying to lift the battery from the case.

- After the battery is totally free of any adhesion, simply lift the battery from the case.

Step 8



- Inspect battery for any leakage.

★ Please follow all U.S. regulations and laws when disposing or recycling the battery.

To reassemble your device, follow these instructions in reverse order.