



Asus VivoBook S200E-RHI3T73 Wifi Chip Replacement

This guide will take you through the steps to replace the Asus VivoBook WiFi Chip.

Written By: Shilo Stuart



This document was generated on 2019-12-26 09:27:34 PM (MST).

INTRODUCTION

If your VivoBook continues to fail to connect to the internet after troubleshooting the internet settings, you may need to replace the WiFi Chip.

TOOLS:

- [Metal Spudger \(1\)](#)
- [Tweezers \(1\)](#)
- [JIS Driver Set \(1\)](#)
- [Phillips #0 Screwdriver \(1\)](#)

Step 1 — Wifi Chip



- With the screen closed, place your laptop upside-down with the front facing you.
- Remove the five black 80mm Phillips #0 screws.
- Remove the four black 50mm Phillips #0 screws.

Step 2



- Use a metal spudger to pry the bottom panel open.

⚠ Be gentle around the edges.

- Lift the back panel to expose the inside of the laptop.

Step 3



- Use a Phillips J0 screwdriver to remove the one black 3mm screw.

Step 4



- Use an up and away motion to pull the module out of its slot.

Step 5



- Use precision tweezers to pry the black wire with a gold plug off the main gold plug on the module.

To reassemble your device, follow these instructions in reverse order.