



Asus ZenBook Flip UX360C Solid State Drive Replacement

Removal and replacement guide for the solid state drive in the Asus ZenBook Flip UX360C

Written By: Jeff Schuitema



INTRODUCTION

If your solid state drive has become slow, has stopped working, or you just need more storage space, you may need to replace it. This guide will walk you through the removal and replacement process for the solid state drive in the Asus ZenBook Flip UX360C.

TOOLS:

- [Anti-Static Wrist Strap \(1\)](#)
- [Phillips #1 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [m.2 SSD \(1\)](#)

Step 1 — Solid State Drive



- Attach an ESD wristband to your wrist and clip the grounding clamp to a grounded metal object.

Step 2




- Remove all eleven 5 mm Phillips #1 screws on the back cover.

Step 3



- Use plastic opening tools to remove the keyboard panel.

Step 4



- Use a plastic opening tool to disconnect the ZIF keyboard ribbon cable from the motherboard.

Step 5



- Unscrew the 5 mm Phillips #1 retaining screw holding the SSD in place.
- Carefully remove the SSD.

To reassemble your device, follow these instructions in reverse order.