



Atari 5200 Controller Start/Pause/Reset Buttons Replacement

A guide to disassembling the Atari 5200 Controller to give its user access to repairing the Start/Pause/Reset List.

Written By: Alan Abelson



This document was generated on 2019-09-19 06:43:20 AM (MST).

INTRODUCTION

The START/PAUSE/RESET buttons of the Atari 5200 controller can become unresponsive due to dirty/overused connections. Opening the controller and reseating/cleaning the interfaces to these sensors can improve the button's responsiveness.

TOOLS:

- [Soft Cloth](#) (1)
- [Isopropyl Alcohol](#) (1)
- [Heavy-Duty Spudger](#) (1)

Step 1 — Opening up the module



- Using a plastic or metal spudger, pry open the face of the button module.

Step 2 — Removing the parts.



- Take off the plate and the rubber buttons.
- Clean the exposed contacts.
- Reassemble by following the steps in reverse.

Test the controller. If these steps don't improve connectivity, take a look at the circuitry replacement guide.