




Canon PowerShot G3 Flash Capacitor Replacement

This guide will discuss how to replace a bad flash capacitor on the Canon PowerShot G3.

Written By: Ryan Riales



INTRODUCTION

The flash of the Canon PowerShot G3 camera is operated by the discharge of a capacitor. A capacitor is an energy storing device that stores a charge between two conducting plates. Before the capacitor can discharge, it must be charged by the battery.

Note:

- 1.) There are many screws to be removed before you can reach the capacitor.
- 2.) To install a new capacitor you must know how to solder wires to the capacitor.
- 3.) Do not continue unless you have a magnetic pad to place the screws and a soldering iron.

TOOLS:


- [Essential Electronics Toolkit](#) (1)
- [Soldering Iron](#) (1)
- [Capacitor Discharge Pen](#) (1)

Step 1 — Flash Capacitor



- Start to remove all of the screws around the camera: from the front, back, sides, and bottom.

Step 2




- Once the screws have been removed, Remove the back panel. The panel should be able to be removed by hand.

Step 3




- Next remove the front panel and right side panels (the left side is part of the front).

Step 4




- Finally, remove the top panel as shown.

Step 5





- The front of camera should now resemble the picture shown.
- To remove the circuit ribbon (the brown strips) pull them out of the plastic pieces they are connected to.

Step 6



- After that you can lift up the capacitor housing by using your finger nail, or other small object, to lift it up around the edges.

Step 7



- Use a spudger, or other thin object, to remove the capacitor from the housing. (Image 2)
- To remove the red and yellow wires connected to the capacitor, use a soldering iron to heat up the solder and a vacuum to suck up the solder. Any other methods you know of will also work.
- Take the capacitor to your local electronics store or order another capacitor online by reading the capacity off of the side of the capacitor. It should be in microFarads (μF).
- Once you have a new capacitor, solder on the red and yellow wires to the same place as the old capacitor.

To reassemble your device, follow these instructions in reverse order.