



# DeWalt DW660 Power Cord Replacement

Use this guide to repair the power cord on your DeWalt DW660

Written By: AL25



## INTRODUCTION

The power cord can simply be replaced by opening the back of the device and unscrewing the casing. Make sure that the device is not plugged in before working on it.

### TOOLS:

- [T20 Torx Screwdriver \(1\)](#)

## Step 1 — Power Cord




- Using a T20 Torx Screwdriver, unscrew the four 19mm screws from the back casing.
- After unscrewing, remove the back casing from the device.

## Step 2




- Disconnect the wires from the switch terminals.

## Step 3



- Remove the ground wire from the motor by pulling it gently.

## Step 4



- Using the T20 Torx screwdriver, unscrew two screws from the bracket that holds the power cord in the casting.

To reassemble your device, follow these instructions in reverse order.