




Dell Studio 1737 Hard Drive Replacement

This guide will give a step by step instruction set of how to remove, replace, and reinstall the laptops hard drive.

Written By: Joseph Jacavone



INTRODUCTION

This guide will show you how to remove or replace the hard drive (HDD) in a Dell Studio 1737.

TOOLS:




- Mako Driver Kit - 64 Precision Bits (1)
- iFixit Opening Tools (1)

Step 1 — Battery





- Slide the battery release slider all the way to the right and push the battery straight out of the back of the computer

Step 2 — Back Panel



- Unscrew the 8 Phillips head screws marked in the photo.
- Even when the screws are fully detached, they will not come out of the panel.
- Use a plastic opening tool to pry the panel away from the laptop body.
- Lift the panel up and away.

Step 3 — Hard Drive



- Detach Hard drive from SATA connector.
- Pull hard drive up and out pulling connector out of the way.

(i) NOTE: your hard drive may be attached by screws or a bracket. This device had the hard drive just placed under the casing.

To reassemble your device, follow these instructions in reverse order.