




# Dell XPS 15 9530 Memory Module Replacement

How to replace the memory modules of a Dell XPS 15 9530.

Written By: Johnathan Hammond



## INTRODUCTION

How to replace the memory modules of a Dell XPS 15 9530.

### TOOLS:

- **Phillips #0 Screwdriver** (1)
- **Spudger** (1)


## Step 1 — Unscrewing the Base-Cover Assembly



- After turning off the system, unscrew the 12 Philips screws (#1) that are on the bottom of the laptop.


 Don't forget to unscrew the two screws hidden under the system badge!

## Step 2 — Prying Off the Base-Cover Assembly




- Using a spudger or some other prying tool (#1), pry off the base-cover assembly from the rest of the system.

## Step 3 — Remove Battery



- Remove the screws that secure the battery to the palm-rest assembly.
  - Disconnect the battery cable from the system board.
  - Lift the battery off the palm-rest assembly.
- (i)*** After you remove the battery, turn the computer over, open the display, and press the power button for about five seconds to ground the system board.

## Step 4 — Remove Memory




- Use your fingertips to carefully spread apart the securing-clips on each end of the memory-module

connector until the memory module pops up.

- Remove the memory module from the memory-module connector.

## Step 5 — Add New Memory Module



- Align the notch on the New memory module with the tab on the memory-module connector.
- Slide the memory module firmly into the connector at a 45-degree angle and press the memory module down until it clicks into place.

*(i)* NOTE: If you do not hear the click, remove the memory module and reinstall it.

To reassemble your device, put the battery back in and reaffix the base-cover assembly to the system.