




# Disassembling Siemens A56 Motherboard Metal Frame

This guide will instruct the user how to remove the metal frame from around the motherboard of the Siemens A56.

Written By: Joseph Casey




This document was generated on 2019-09-18 02:50:30 PM (MST).

 **TOOLS:**

- T5 Torx Screwdriver (1)

## Step 1 — Front Plate



- Firmly grasp the white casing of the phone with one hand and the blue cover with the other hand as seen in the first picture.
- Pull up on the two plastic clips at the top of the phone.
- While the clips are pulled up, pull the blue cover away from the white casing to remove it.


## Step 2 — Back Plastic Cover



- Along the side of the metal frame of the phone, locate the six screws.
- Using a T5 screwdriver bit, unscrew the six 1/4 inch screws and store them in a safe place.

**⚠** The screws are very small and can strip easily, so proper care is required when removing and storing the screws.

## Step 3



- To remove the back plastic cover, grasp the device with both hands as seen in the first picture.
- Gently remove the motherboard from the back plastic cover.

! The motherboard is fragile, so proper care is necessary when handling and storing in order to prevent damage.

## Step 4 — Motherboard Metal Frame



- Turn over the keypad interface and using the blue plastic opening tool, gently pry the bottom of the metal frame.
- Once loosened, the metal frame should be able to be lifted from the motherboard.

To reassemble your device, follow these instructions in reverse order.