



HP ProBook 440 G1 Hard disc drive Replacement

Replacing the Hard disc drive HP ProBook 440 G1 by using Phillips #00 Screwdrive.

Written By: Muhammad Asymam Bin Mohd Azmi




INTRODUCTION

In this guide, we took down the computer step by step to try to solve the problem. This guide is going to give you a better understanding of how we take this computer down in each part. To be more precise, this guide will show step by steps on how to replace the hard disc drive.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Hard disc drive




- Firstly, push and hold the tab on the right and left of the laptop to the center

Step 2




- Pull the battery out from the laptop

Step 3




- Push and hold the tabs on the left and right to the center again to remove the backplate.

Step 4



- Now slide backplate off
- Locate the hard drive, opposite the battery across from the wireless card.

Step 5



- Next, remove all four Phillips #00 screws that hold the hard drive in place.

Step 6



- Pull the hard drive out.
- The HDD should slide out after all screws are removed.

To reassemble your device, follow these instructions in reverse order.