




# Hasbro Bop-It Micro Series Speaker Replacement

This guide will walk you through replacing the speaker inside your Bop-It Micro Series.

Written By: Glenn Haag



 **TOOLS:**


- [Phillips #0 Screwdriver \(1\)](#)
- [Soldering Iron \(1\)](#)

## Step 1 — Back Cover




- Using a #0 phillips screwdriver, remove the (2) #4 Phillips head 8mm screws holding the back cover on. Note that the screws are captured in the back cover, so they do not need to be completely removed.

## Step 2




- Remove the (6) #3 Phillips head 6 mm screws shown in any order, also using the #0 phillips screwdriver. When removing the final screw, hold the assembly together. There is a spring inside the device which will pop the assembly apart when all the screws are removed.

## Step 3




- Carefully separate the two sections, leaving them connected by the wires. At this point, your device should look like this. This completes the teardown.

## Step 4 — Speaker



- Remove the (3) #3 Phillips head 6 mm screws using your Phillips #0 screwdriver, and remove the plastic with your fingers.

## Step 5



- De-solder the speaker from the wires. Refer to the [soldering guide](#) for instructions on how to solder

Follow the steps of this guide in reverse to reassemble.