



How to Replace Scott Mountain Bike Handlebars

Learn how to replace the handlebars on your Scott Mountain Bike.

Written By: Sean Slater



INTRODUCTION

Need to replace the handlebars on your mountain bike? This guide will show you how to replace it so the bike is good as new.

TOOLS:

- [H4 Hex Wrench \(1\)](#)
- [H3 Hex Wrench \(1\)](#)
- [Flathead Screwdriver \(1\)](#)

PARTS:

- [Scott Mountain Bike \(1\)](#)
- [Handlebars \(1\)](#)

Step 1 — Scott Mountain Bike Handlebars



- Prop bike upright
- Unscrew the hex bolts holding the front and rear shifter in place.
 - Use the H4 size hex wrench
- Repeat for other side of handlebars.

Step 2



- Slide the shifters toward the center of the handlebars so there is a gap between them and the grips.
- Repeat for other side of handlebars.

Step 3



- Use a flathead screwdriver to wedge a gap between the grip and the handlebars.
- Twist grip around until it comes off of handlebar.
- Repeat for other side of handlebars.

Step 4



- Slide the shifters off of the end of the handlebars.
- Let them hang on the bike.
- Repeat for other side of handlebars.

Step 5



- Unscrew the hex bolts holding the center bracket in place.
 - Use H3 hex wrench.
- Place center bracket and hex screws off to the side. They will be needed in the next step.

Step 6



- Attach new handlebars and screw the center bracket back in place.
- Make sure that handlebars are centered.

Step 7



- Slide the shifters back onto the handlebars so that the numbers are upright.
- Do not screw them back in place yet.

Step 8



- Slide the handlebar grips back onto the ends of the handlebars.
- Slide the shifters back against the grips and screw them into place.

By following these steps, you will have your bike ready in no time.