




How to reset the SMC, PRAM and NVRAM on an iMac Pro

iMac Pro acting strange? These resets may be able to help!

Written By: Aaron Cooke



INTRODUCTION

I had to make a separate guide for this Mac as this Mac has the new T2 chip and requires a different procedure then the other Mac Desktops.

Step 1 — SMC reset Part 1



- Choose Apple menu > Shut Down.
- After your Mac shuts down, press and hold its power button for 10 seconds.
- Release the power button, then wait a few seconds.
- Press the power button again to turn on your Mac.


i If that did not solve the issue, move on to Step 2

Step 2 — SMC Reset Part 2



- Choose Apple menu > Shut Down.
- After your Mac shuts down, unplug the power cord.
- Wait 15 seconds.
- Plug the power cord back in.
- Wait 5 seconds, then press the power button again to turn on your Mac.

Step 3 — PRAM and NVRAM reset



- Shut down your Mac.
- Then turn it on and immediately press and hold these four keys together: Option, Command, P, and R.
- You can release the keys after about 20 seconds, during which your Mac might appear to restart.
- You can release the keys after the Apple logo appears and disappears for the second time.

i You **must** have a wired keyboard made by Apple in order for this to work.

i You can buy one from Amazon [here](#).

If you have tried all of these resets and still have problems, head on over to our Answers Forum!