




Lenovo IdeaPad S400 Touch Hard Drive Replacement

How to replace the hard drive in a Lenovo IdeaPad S400 Touch.

Written By: Max Hoyle




INTRODUCTION

If you need to replace the hard drive, follow this guide. For this guide you will need Phillips #0 screwdriver, from the iFixit tool kit to remove the back case. You will need a plastic spudger to remove the casing.

TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Battery




- Turn your computer over so the back is face up.
- Use your forefinger to unlock the two tabs located on the back. Slide the tabs until you see the red showing.
- The battery cover will then pop up allowing you access to the battery.

Step 2 — Hard Drive



- Remove the five 6mm Phillips #0 screws from the back panel.
- Pull back the rubber tabs from the corners of the laptop backing to expose the screws.
- *(i)* The two tabs next to the battery flip toward the battery. The two remaining tabs flip down, away from the battery.
- Remove the four 4mm Phillips #0 screws that are underneath the rubber tabs.
- Remove the three 6mm Phillips #0 screws from under the battery.



Step 3



- Slide the back panel away to remove it.

i Don't be afraid to apply force when removing the back panel.

Step 4



- Remove the two 3mm Phillips #0 screws that hold the hard drive to the case.
- Take out the hard drive by lifting and sliding it at the same time.

To reassemble your device, follow these instructions in reverse order.