




Lenovo ThinkPad Yoga 260 Repair Battery Replacement

If your battery is not functioning properly, this guide will highlight the steps on how to replace it.

Written By: Daniel Fernandez



INTRODUCTION

If your battery is not functioning properly, this guide will highlight the steps on how to replace it.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover



(i) Ensure the device is off and unplugged.

- Remove the stylus from its port and set aside.

Step 2



- Using a Phillips #1 screwdriver, gently unscrew the eight 1.3 mm Phillips #1 screws until you hear an audible click.

(i) The screws will not separate from the bottom cover when loose.


Step 3



(i) The bottom cover is attached via several plastic clips located around the edges of the bottom cover.

- Using a plastic opening tool, gently pry the bottom cover from the laptop.
- Work the plastic opening tool around the edges of the bottom cover undoing all of the plastic clips, as shown in the picture.

Step 4



- Place your fingers around the edges of the cover and remove it.

Step 5 — Battery



- Fold back the plastic cover to access the battery connection.
- Remove the battery connection using your two index fingers.

ⓘ Gently separate the connectors.

Step 6



- Unscrew the two 1.3 mm Phillips #1 fasteners using a Phillips #1 screwdriver and set them aside.
- Lift the battery free from its mounting and remove it.

To reassemble your device, follow these instructions in reverse order.