



Lenovo Yoga 720-15IKB Speaker Replacement


How to correctly replace the speakers in your Lenovo Yoga 720 15-IKB

Written By: David Kay

TOOLS:

- [T5 Torx Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)



Step 1 — Bottom Cover



(i) Start by flipping the device over so that you see the screws.

- Remove the 7 T5 short screws.
- Remove the 3 long T5 screws.

Step 2



- Starting at the left USB port use you opening tool to gently pry up the bottom case.
- ⚠ Make sure you are prying on the cover itself, not the metal shield around the USB port.
- Pry along the laptop's edge as shown by the arrows.
- ⚠ Do NOT pry along the top side, or you will damage the casing. Stay with the arrows.

Step 3




- Lift the case from the bottom side.
NOT the side with the hinges.
- ⚠ When you feel resistance, do NOT keep lifting or you will damage the housing.
- Once you feel resistance, gently pull the case towards you. (away from the hinges.)
- Remove the bottom case.

Step 4 — Battery



- Unplug the battery connector

Step 5 — Unplug Speaker cable



- Unplug the speaker cable.

To reassemble your device, follow these instructions in reverse order.