



# MacBook Core 2 Duo Memory Cover Replacement

Written By: iRobot



## INTRODUCTION

This keeps the RAM levers out of the way of the battery and secures the hard drive.

### TOOLS:

- [Coin](#) (1)
- [Phillips #00 Screwdriver](#) (1)

### PARTS:

- [MacBook Memory Cover](#) (1)

## Step 1 — Battery



- Use a coin or spudger to rotate the battery-locking screw 90 degrees clockwise.

## Step 2



- Lift the battery out of the computer.

## Step 3 — Memory Cover



- Unscrew the three evenly-spaced Phillips screws from along the rear wall of the battery compartment.

-  The screws are captive to the metal memory cover so you cannot lose them.

## Step 4



- Rotate the L-shaped memory cover so it clears the battery compartment opening and lift it up and out of the computer.

To reassemble your device, follow these instructions in reverse order.