



MacBook Pro 15" Unibody Late 2008 and Early 2009 Hard Drive Replacement

Written By: Walter Galan



INTRODUCTION

Hard drive jam packed with files? Replacing your hard drive is easy.

TOOLS:

- Phillips #00 Screwdriver (1)

PARTS:


- 320 GB 5400 RPM 2.5" Hard Drive (1)
- 320 GB 7200 RPM Seagate SATA Hard Drive (New) (1)
- 500 GB 5400 RPM 2.5" Hard Drive (1)
- 500 GB 7200 RPM 2.5" Hard Drive (1)

Step 1 — Access Door



- With the case closed, place the Unibody top-side down on a flat surface.
- Depress the grooved side of the access door release latch enough to grab the free end. Lift the release latch until it is vertical.

Step 2



- The access door should now be raised enough to lift it up and out of the Unibody.

Step 3 — Battery



i Be sure the access door release latch is vertical before proceeding.

- Grab the translucent plastic tab and pull the battery up and out of the Unibody.
- If the latch is depressed it will lock the battery in place.

Step 4 — Hard Drive



- Remove the single Phillips screw securing the hard drive bracket to the upper case.

↗ This screw is captive to the hard drive bracket.

Step 5



- Lift the hard drive by its pull tab enough to grab and remove the retaining bracket.
- Lift the hard drive out of the upper case, minding the cable attaching it to the computer.

Step 6



- Remove the hard drive from its cable by pulling the cable connector straight away from the drive.

To reassemble your device, follow these instructions in reverse order.