



MacBook Unibody Model A1278 Hard Drive Replacement

Written By: Andrew Bookholt



INTRODUCTION

When replacing your hard drive, you must transfer the Torx screws from the old drive to the new one.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)
- [T6 Torx Screwdriver](#) (1)

PARTS:


- [MacBook and MacBook Pro \(Non-Retina\) SSD Upgrade Bundle](#) (1)
- [250 GB SSD](#) (1)
- [500 GB SSD](#) (1)
- [1 TB SSD](#) (1)
- [500 GB SSD Hybrid 2.5" Hard Drive](#) (1)
- [500 GB 5400 RPM 2.5" Hard Drive](#) (1)
- [1 TB 5400 RPM 2.5" Hard Drive](#) (1)
- [MacBook Unibody \(Model No. A1278\) Hard Drive Bracket](#) (1)
- [Universal Drive Adapter](#) (1)

Step 1 — Access Door



- With the case closed, place the Unibody top-side down on a flat surface.
- Depress the grooved side of the access door release latch enough to grab the free end. Lift the release latch until it is vertical.

Step 2



- The access door should now be raised enough to lift it up and out of the Unibody.

Step 3 — Battery



- ⓘ Be sure the access door release latch is vertical before proceeding.
- Grab the white plastic tab and pull the battery up and out of the Unibody.

Step 4 — Hard Drive



- Remove the single Phillips screw securing the hard drive bracket to the upper case.
- ⓘ This screw is captive to the hard drive bracket.

Step 5



- Lift the hard drive by its pull tab enough to grab and remove the retaining bracket.
- Lift the hard drive out of the chassis, minding the cable attaching it to the computer.

Step 6



- Remove the hard drive from its cable by pulling the cable connector straight away from the drive.
- Hard drive remains.

Step 7 — Hard Drive



- Remove the two T6 Torx screws from each side of the hard drive (four screws total).
(i) You'll need to transfer these screws to your new hard drive if you're changing drives.
(i) If you are installing a new hard drive, we have an [OS X install guide](#) to get you up and running.

To reassemble your device, follow these instructions in reverse order.