



# MacBook Unibody Model A1278 Lower Case Replacement

Written By: Walter Galan



## INTRODUCTION

Replace the aluminum bottom case in a MacBook Unibody.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)

### PARTS:


- [MacBook Unibody \(Model No. A1278\) Lower Case](#) (1)
- [MacBook and MacBook Pro Unibody Plastic Feet](#) (1)

## Step 1 — Access Door



- With the case closed, place the Unibody top-side down on a flat surface.
- Depress the grooved side of the access door release latch enough to grab the free end. Lift the release latch until it is vertical.

## Step 2




- The access door should now be raised enough to lift it up and out of the Unibody.

## Step 3 — Battery



- Be sure the access door release latch is vertical before proceeding.
- Grab the white plastic tab and pull the battery up and out of the Unibody.

## Step 4 — Lower Case



- Remove the following eight screws securing the lower case to the chassis:
  - One 3 mm Phillips screw.
  - Three 13.5 mm Phillips screws.
  - Four 3.5 mm Phillips screws.

## Step 5



- Using both hands, lift and remove the lower case off the upper case.

To reassemble your device, follow these instructions in reverse order.