



# Minolta QTsi Maxxum Shutter Button Replacement

This guide will show you how to replace the shutter release button.

Written By: Jordan Ellery



## INTRODUCTION

Replace your broken shutter release button so that you can take pictures with your camera.

### TOOLS:

- [Coin](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Metal Spudger](#) (1)

## Step 1 — Shutter Button



- Locate the battery compartment on the bottom panel of the camera.
- Open the battery door by using a coin.
- In the counterclockwise direction, twist the coin in the battery door groove to open it.

## Step 2



- (i)* Two batteries are located inside the battery chamber.
- Remove the two batteries from the battery chamber by picking them up.

## Step 3



- There is a screw located underneath the batteries in the battery compartment.
  - Unscrew and remove the (1) black Phillips #00 5mm screw from the battery compartment.
- !** Ensure good lighting before attempting to remove this screw because it is hard to see inside the compartment.

## Step 4



- From underneath the flash assembly, remove the (1) black Phillips #00 5mm screw
- !** Be careful because you can lose the screw

## Step 5



**i** The only screws remaining that hold the top panel of the camera in place are located next to the view finder.

- Remove the (2) black Phillips #00 5mm screws from both sides of the view finder.

**!** Be careful because you can lose the screw

## Step 6



**i** The top panel of the camera should now be easy to lift off. If it is not, make sure that all screws and attachments, listed in steps 1-5, have been removed.

- Once all screws are removed, lift the top panel from the camera.

**!** Be careful when removing the top panel because there are wires connected to it.

This document was generated on 2019-09-22 01:13:11 AM (MST).

## Step 7



- Use a metal spudger to push the button out of its socket so that you can place a new one in its place.

To reassemble your device, follow these instructions in reverse order.