




# Motorola MBP33SBU Parent Unit Speaker Replacement

This guide shows how to replace the speaker in the parent unit of your baby monitor.

Written By: Ely Tilley



## INTRODUCTION

In this guide you will be taught how to take apart the plastic shell of your parent unit and remove the speaker. Some soldering will be required to fully replace the speaker.

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Tweezers](#) (1)

## Step 1 — Battery




- Using the Phillips #1 screwdriver, remove the battery cover screw.
- Remove the battery cover from its hinges and set aside.

## Step 2



- Lift the battery from its slot.
- Using precision tweezers, grip the connector plug.
- Wiggle the connector plug and pull up to remove the connecting wires.
- Remove the battery from the unit and set it aside.


## Step 3 — Parent Unit Speaker



- Using the Phillips #1 screwdriver, remove the 7mm screw under the battery cover.
- Using the blue plastic opening tools, begin prying open the corners and disconnecting the seven clasps around the edges of the parent unit.



*(i)* There should be seven plastic clasps that hook the top portion of the plastic shell to the bottom. These clasps may become damaged while disassembling.

## Step 4



- Grip the speaker's metal clasp with tweezers and then pull on the clasp to remove.
- If pulling on the clasp is not working, try gripping the clasp with the tweezers again. Then tilt the tweezers towards the speaker. This should press the metal of the tweezers against the plastic holding the speaker in place and create enough leverage to pop the clasp out of place.

## Step 5



- Desolder the wires connecting the speaker to the circuit board.

⚠ Beware of overheating, the soldering kit is capable of damaging the circuit board.

⚠ Beware of the potential for personal injury from heated metals.

ⓘ For soldering procedures please refer to iFixit's guide to [Soldering Skills](#)

To reassemble your device, follow these instructions in reverse order.