



Motorola V60c Keypad and Keypad Logic Board Replacement

Written By: Ryan Kuroiwa



INTRODUCTION

How to replace the keypad and keypad logic board.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [T6 Torx Screwdriver](#) (1)

Step 1 — Battery



- Depress the silver button.
- Pull from top of phone to lift the cover.

Step 2




- Hold battery from both sides at the bottom.
- Push upwards and gently lift to remove.

Step 3 — Keypad and Keypad Logic Board



- Remove 4 screws from corners using T-6 screwdriver.
- (i)* NOTE: Bottom two screws are gold.
- (i)* NOTE: Make sure screws return to correct place when reassembling.

Step 4



- Use plastic opening tool to pry up back cover from two side clips.


(i) NOTE: Sticker might be attached to rest of phone.

Step 5



- Remove the back cover.

Step 6



- Use a plastic opening tool to gently remove the orange ribbon cable.
- Lift up the main logic board.
- NOTE: Rubber side buttons are not secure and might detach from the main logic board during removal.

This document was generated on 2019-10-14 01:30:10 PM (MST).


Step 7



- Remove the keypad logic board.

(i) NOTE: Plastic spacer is not secured to keypad logic board and might detach during removal.

Step 8



- Remove the keypad.

To reassemble your device, follow these instructions in reverse order.