



# Parrot FLYPAD Joystick Replacement

This guide will demonstrate how to replace the joystick on the Parrot Flypad.

Written By: HUY NGUYEN




## INTRODUCTION

This guide will walk you through steps to replace your joystick.

### TOOLS:

- [T6 Torx Screwdriver](#) (1)
- [Magnetic Project Mat](#) (1)
- [Phillips #0 Screwdriver](#) (1)

## Step 1 — Joystick



**i** Total of 6 Screws are located in the back of the controller.

- Four 0.9mm T6 screws
- Two 0.1mm T6 screws
- Flip the Flypad over.
- Remove the six screws using a T6 screwdriver.

**i** Use a Magnetic Mat to prevent loss of screws. Set aside.

## Step 2




- Flip the Flypad over again and separate the front and back. Be sure to remove the foam adhesive that connects the front plate to the motherboard.

 Be aware that the Buttons (L1,R1) may fall out. Remember to put them back in place during reassembly.


- Use Ph0 tool to remove the screws holding the motherboard in place.
- Gently remove the motherboard from the front plate.

## Step 3



- Pop the joysticks out by pulling gently.

## Step 4



- Unscrew and replace joystick caps for a more comfortable grip.

To reassemble your device, follow these instructions in reverse order.