



# Raleigh M20 Handlebars Replacement

This guide will show you how to replace a broken pair of handlebars.

Written By: Jon Ribera



 **TOOLS:**

- 3/8" Allen Wrench (1)

 **PARTS:**

- New handlebars (1)

## Step 1 — Handlebars




- ⓘ Strip all the accessories from your old handlebars. (reflectors, mirrors, etc...)
  - Using a 3/8" Allen wrench, loosen the nuts that hold the brake controls and gear shifters.

## Step 2



- Place an Allen wrench (size doesn't matter) under the bike grip.
  - Twist the grip back and forth while pulling on the Allen wrench to remove the grip.

## Step 3



- Slide off the gear shifters.
- Slide off the brake controls.

## Step 4



- Loosen the central nut on the faceplate that connects the bars to the steering column. If the bars are secured by a faceplate with a detachable top, loosen the nuts on the faceplate and remove.
- Lift the handlebars from the bike frame.

*(i)* Move the bars until they're in the correct position for your stance. Tighten the faceplate nuts with a 3/8" Allen wrench to firmly secure the handlebars in place.

*(i)* Sit on the bike and make final adjustments to the positioning of the brakes and gears.

To reinstall the handlebars, complete these steps in reverse order. If there is a problem with the alignment, return to the handlebar repair guide and repeat step 4.