Spin Master Hatchimal Draggle Speaker Replacement

The speaker may not work properly, this guide will show how to easily change out the device speaker.

Written By: Hector Lopez

INTRODUCTION

Step by step instructional guide to replacing Spin Master Hatchimal Draggle speaker. Before getting started, fur and wing removal is required.

🔧 TOOLS:

- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)
- Utility Scissors (1)
- Spudger (1)

This document was generated on 2019-09-22 01:58:37 PM (MST).

Step 1 — Plastic Wing Replacement

- lay the Hatchimal on its side.

Step 2

- Using the plastic opening tool, push in on the purple clip.

Step 3

● Pull the wing off of the hatchimal.

ⓘ The wing should come off with little resistance.

Step 4 — Fur Replacement

● Cut the fur retaining zip-tie with a pair of scissors.

Step 5

- Lift the fur up until it can't go further.

Step 6

- Use the spudger tool to push up on the black clip to free it.

- Pull the clip out.

Step 7

- Lift fur up to reveal the next set of clips.

- Insert a spudger to push up on the black clip to free it.

- Pull out the clip.

Step 8

- Lift the fur up and over the Hatchimals Head.

- Remove the six 12mm Phillips #00 screws from then body.

Step 9

- Pull the casing apart.

- Remove the yellow speaker cable.

Step 10

- Remove the three 7mm Phillips #00 screws from the head.

- Remove the wheel base and the circuit board carefully not to damage the spring.

This document was generated on 2019-09-22 01:58:37 PM (MST).

© iFixit — CC BY-NC-SA | www.iFixit.com | Page 7 of 10

Step 11

- Push the six black fur clips out using the spudger.

- Remove the fur completely.

Step 12 — Speaker Replacement

- Gently pull the yellow speaker cord from circuit board. There will be little resistance.

Step 13

- Remove the two 7mm Philips #00 screws from the head.

Step 14

- Pull the speaker cover off.
- Remove the speaker.

This document was generated on 2019-09-22 01:58:37 PM (MST).

To reassemble your device, follow these instructions in reverse order.