



# Toshiba Satellite P755 S5390 Touchpad Repair

Repair a disconnected touchpad on your Toshiba Satellite laptop.

Written By: Dominic Oldani



## INTRODUCTION

A broken touchpad is annoying on any laptop. Sometimes this is an easy fix. Use this guide to fix a disconnected touchpad on your Toshiba Satellite P755 S5390.

### TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

## Step 1 — Toshiba Satellite P755 S5390 Touchpad Repair



*(i)* Make sure that your laptop is powered off before continuing.


- Close the laptop lid and turn it over so that the spine is facing away from you.
- Slide the left slider, which is to the left the battery compartment, into its leftmost position.

## Step 2




- Slide and hold the right slider into its rightmost position.
- Lift the battery out of the compartment.

## Step 3




- Remove fifteen Phillips #1 screws from the back of the laptop.

## Step 4



- Turn the laptop back over and open the lid.


## Step 5



- Gently pry up the keyboard.
- Continue to pry off the rest of the keyboard.


 Don't touch the motherboard.

## Step 6



- Check if the touch pad cable is plugged into the ZIF connector on the motherboard.

## Step 7



- Grab the blue plastic above the touch pad wire.
- While holding the blue plastic piece, firmly plug the cable into its socket on the motherboard.

To reassemble your device, follow these instructions in reverse order.