



iMac G5 17" Model A1144 Hard Drive Replacement

Written By: Walter Galan



INTRODUCTION

Upgrade your hard drive for an instant increase in storage space!

TOOLS:

- Phillips #1 Screwdriver (1)
- Plastic Cards (1)
- Spudger (1)
- T10 Torx Screwdriver (1)
- T6 Torx Screwdriver (1)
- T8 Torx Screwdriver (1)

PARTS:

- 2 TB SATA Desktop Hard Drive (1)
- 1 TB SATA Desktop Hard Drive (1)
- 3 TB SATA Desktop Hard Drive (1)
- Universal Drive Adapter (1)
- 4 TB 3.5" Hard Drive (1)
- 2 TB SSD Hybrid 3.5" Hard Drive (1)
- 1 TB SSD Hybrid 3.5" Hard Drive (1)
- 4 TB SSD Hybrid 3.5" Hard Drive (1)

Step 1 — Access Door



⚠ Before you work on the computer, unplug the computer and press the power button for 20-30 seconds to drain the stored energy in the power supply.

- Loosen the two Phillips screws securing the access door to your iMac.
- **i** These screws are captive in the access door.

Step 2




- Remove the access door from your iMac.

Step 3 — Front Bezel



- Remove the three T8 Torx screws securing the front bezel to the rear panel.

Step 4



- ① Orient the iMac face-up, on its backside.

- Use your thumbs to press both RAM arms in past the front bezel for enough clearance to lift it off the rear case.

Step 5



- While holding the RAM arms in with your thumbs, lift the lower edge of the front bezel enough to clear the rear case.

Step 6



(i) Re-orient your iMac so it sits upright on the stand.

- Insert a plastic card up into the corner of the air vent slot at the top of the rear case.
- Push the card toward the top of the iMac to release the front bezel latch.
- Pull the front bezel away from the rear case.
- Repeat this process for the other side of the front bezel.

(i) It may be necessary to apply several layers of duct tape to the top of the access card to aid in releasing the latches.


(i) If the bezel refuses to release, try pressing the lower edge back onto the rear case and repeat this opening process.

Step 7




- Lay your iMac stand-side down on a table.
- Lift the front bezel from its lower edge and rotate it away from the rest of your iMac, minding the RAM arms that may get caught.
- Lay the front bezel above the rest of the iMac.

Step 8



- If necessary, remove the piece of kapton tape wrapped around the microphone and camera cables.

Step 9



- Disconnect both the camera and microphone cables.

Step 10 — Display





- Peel back the aluminum EMI shield up off the lower three edges of the rear case.

(i) It is not necessary to peel the EMI shield off the display.


(i) We found it helpful to tape the EMI shield up against the display to keep it out of the way.

Step 11




- Remove the two 5 mm T6 Torx screws securing the display data cable to the logic board.
- Using its attached black tab, pull the display data cable connector up off the logic board.

Step 12



- Pull the inverter cable connector up off its socket on the logic board.


Step 13



- Peel back the aluminum EMI tape from the two vertical edges of the display.

 During reassembly, it is helpful to use several small strips of tape to hold the EMI shielding along the left and right edges of the display footprint out of the way before lowering the display into the rear case of your iMac.

Step 14



- Remove the four recessed coarse-thread 7.5 mm T10 Torx screws securing the display to the rear case.

 These screws are recessed, so a thin screwdriver such as [this](#) is essential for removal. Bit drivers tend to be too short for this application.

Step 15




- Lift the display from its lower edge and pull it toward yourself to peel it off the EMI shield attached to its top edge.
- *i* Be mindful of any cables that may get caught during removal.

Step 16 — Hard Drive



- Disconnect the hard drive thermal sensor by pulling the connector away from its socket parallel to the face of the hard drive.

Step 17




⚠ Pressing the top of the hard drive bracket down to release it from the rear case requires a substantial amount of force, so we recommend laying your iMac stand-side down on a table to avoid knocking it over.

- Press the hard drive bracket down toward the bottom edge of your iMac to free it from the rear case, then rotate the top of the drive toward yourself.
- Lift the hard drive off its lower pins and pull it out of the rear case, minding the cables that are still attached.


★ When reinstalling the hard drive, be careful not to push the rubber grommets through the chassis with the hard drive pins as retrieving them may require logic board removal.

Step 18




- Insert the flat end of a spudger into the gap between the SATA power connector and the hard drive.
- Twist the spudger to separate the SATA power connector from the hard drive.
- Pull the SATA power connector away from the hard drive.

Step 19



- Pull the SATA data cable away from the hard drive.
- Hard drive remains.

Step 20 — Hard Drive



- Remove the two T8 Torx screws securing the upper bracket to the hard drive.


 Transfer the bracket and screws to your new hard drive.

Step 21



- Remove the two T8 Torx pins on the connector side of the hard drive and transfer them to your new hard drive.

Step 22



- Use the flat end of a spudger to pry the hard drive thermal sensor off the hard drive.

 Don't forget to transfer this to your new drive.

 If you are installing a new hard drive, we have an [OS X install guide](#) to get you up and running.

To reassemble your device, follow these instructions in reverse order.