




# iMac Intel 21.5" EMC 2428 AirPort Card Replacement

Replace the AirPort card in your iMac Intel 21.5" EMC 2428.

Written By: Walter Galan



## INTRODUCTION

Replace a broken AirPort card to regain Wi-Fi connectivity.


### TOOLS:

- Heavy-Duty Suction Cups (Pair) (1)
- Spudger (1)
- T10 Torx Screwdriver (1)
- T6 Torx Screwdriver (1)

### PARTS:


- iMac Intel 21.5" (EMC No. 2428) Airport/Bluetooth Board (1)

## Step 1 — Glass Panel



- ① Before beginning, unplug your iMac and lay it on a soft surface as shown.
- Stick a suction cup near each of the two top corners of the glass panel.
- ① To attach the [suction cups](#) we sell, first position the suction cup with the movable handle parallel to the face of the glass panel. While lightly holding the suction cup against the glass, raise the movable handle until it is parallel with the other handle.
- If your suction cups refuse to stick, try cleaning both the glass panel and the suction cup with a mild solvent.

## Step 2



- Gently lift the glass panel perpendicular to the face of the LCD enough to clear the steel mounting pins attached along the underside of the top edge of the glass panel.
- Pull the glass panel away from the lower edge of the iMac and carefully set it aside.

★ During reinstallation, be sure to meticulously clean the inside of the glass panel and the face of the LCD as any dust or fingerprints trapped inside will be annoyingly visible when the machine is turned on.

## Step 3 — Display



- Remove the eight 8 mm T10 Torx screws securing the display to the outer case.

ⓘ The last two pictures are detail shots of each side of the display.

This document was generated on 2019-09-17 06:01:24 PM (MST).



## Step 4



- Slightly lift the top edge of the display out of the outer case.


**⚠** Do not lift it too much. There are several cables attaching the display to the logic board. Twisting or pulling the display assembly with the cables attached will damage your iMac.

## Step 5



- Pull the vertical sync cable connector out of its socket on the LED driver board near the top left corner of your iMac.

## Step 6



- Rotate the display out of the outer case enough to disconnect the LED backlight power cable from the LED driver board.
- Disconnect the LED backlight power cable by depressing the locking mechanism while pulling the connector away from its socket (toward the bottom edge of the iMac).



## Step 7



- Grab the plastic pull tab secured to the display data cable lock and rotate it towards upwards.
- Pull the display data cable straight out of its socket on the logic board.

● Do not lift up on the display data cable, as its socket is very fragile. Pull the cable parallel to the face of the logic board.

## Step 8




- Disconnect the LCD thermal sensor cable connector from its socket on the logic board.

## Step 9




- Carefully pull the display toward the top edge of your iMac and lift it out of the outer case, minding any cables that may get caught.

## Step 10 — AirPort Card




- Use the flat end of a spudger to pry all three AirPort antenna cable connectors up from their sockets on the AirPort card.
- ▣ During reinstallation, connect the cable with no stripes to the socket marked CH0, the cable with one stripe to CH1, and the cable with two stripes to CH2.

## Step 11



- Remove the single 5.3 mm T6 Torx screw securing the AirPort card to its socket.

## Step 12



- Pull the AirPort card away from its socket and remove it from the iMac.

To reassemble your device, follow these instructions in reverse order.