




# iPhone 7 Power and Volume Control Cable Battery Replacement

prereq only

Written By: Scott Havard



# INTRODUCTION

prereq only


## TOOLS:

- Spudger (1)
- ESD Safe Tweezers Blunt Nose (1)
- iOpener (1)
- Plastic Cards (1)
- Mako Driver Kit - 64 Precision Bits (1)

## PARTS:

- iPhone 7 Replacement Battery (1)

## Step 1 — Power and Volume Control Cable Battery




- Use the flat end of a spudger to disconnect the Taptic Engine connector from its socket on the logic board.

## Step 2




- Remove the three 1.6 mm Phillips screws securing the Taptic Engine to the rear case.

## Step 3



- Remove the Taptic Engine.

## Step 4



- Use a pair of tweezers with blunt tips to peel back one of the adhesive strips on the lower edge of the battery.

## Step 5



- Use a pair of tweezers with blunt tips to peel back the other adhesive strip on the lower edge of the battery.

## Step 6



**⚠** Try to keep the strips flat and unwrinkled during this procedure; wrinkled strips will stick together and break instead of pulling out cleanly.

- Slowly pull one battery adhesive tab away from the battery, toward the bottom of the iPhone.
- Pull steadily, maintaining constant tension on the strip until it slips out from between the battery and the rear case. For best results, pull the strip at a 60° angle or less.
- **(i)** The strip will stretch to many times its original length. Continue pulling and re-grab the strip near the battery if necessary.

## Step 7



- Repeat the previous step for the second strip.
- **Hold down the battery as you remove the second strip, or the strip may fling the battery when it separates from the case.**
- **If you removed both adhesive strips successfully, skip the next step.**
- Otherwise, if either of the adhesive strips broke off underneath the battery and could not be retrieved, **continue with the next step below.**

## Step 8



- **(i)** If you successfully removed both adhesive strips, move on to the next step. Otherwise, you will need to pry the battery from the rear case.
  - Prepare an iOpener and apply it to the back of the rear case, directly over the battery. Alternatively, you can apply heat using a heat gun or hair dryer.
  - After about a minute, remove the iOpener, flip the phone over and use a plastic card to break up any remaining adhesive behind the battery.
- ⚠** Avoid bending the battery. Damage to the battery may release dangerous chemicals, and could start a fire.
- ⚠** Do not pry under the top third of the battery, you may damage the volume button ribbon cable.

## Step 9



- Remove the battery.

☞ When installing the battery, refer to [this guide](#) to replace your battery's adhesive strips.

To reassemble your device, follow these instructions in reverse order.